



## Fire Safety Guidelines

### 1. Location and Supervision:

- Use the PyroPod in an open, ventilated area on a stable, non-flammable surface. Keep children and pets at a safe distance and never leave the fire unattended.

### 2. Fuel Handling:

- Use only recommended fuels: kindling, non-smoking wood chips, or wood pellets. Do not overfill; keep fuel below the top outlet holes to maintain the smokeless function.

### 3. Ignition:

- Light safely using fire lighters or a direct flame. Avoid using flammable liquids.

### 4. Fire Control:

- Keep water, sand, or a fire extinguisher nearby. Avoid using water to extinguish the fire unless in an emergency.

### 5. Weather Conditions:

- Do not use the PyroPod in windy or dry, fire-prone conditions to prevent uncontrolled spread.

### 6. Post-Use:

- Let the fire burn out naturally and allow it to cool completely before handling. Do not leave until the fire is fully extinguished.

### 7. Ash Disposal:

- Safely dispose of ashes once they are cold. Store the PyroPod only after it has completely cooled down.

**Important: Follow local fire regulations and enjoy your PyroPod responsibly!**

**Please visit our FAQ on our website or email us for any questions or queries**

[www.pyropod.nz](http://www.pyropod.nz) | [shop@pyropod.nz](mailto:shop@pyropod.nz)